




Institutional Television
www.philipsitv.com

RC2573GR

New Master Setup Remote

Directions For Use

Guest / Setup Mode Switch



(DCM mode not used)



Guest Mode
↑
Setup Mode

REPLACES / FULLY INTERCHANGEABLE WITH RG4172BK MASTER SETUP REMOTE




RG4172BK (Black)

Alpha / Soft Keys



RC2573GR (Green)



2-AA Cells Required

Let's make things better.



PHILIPS

Philips Institutional TV Software

Philips Institutional Televisions can be configured to operate in either "Consumer" or "Commercial" operational modes. The master setup remote is required to identify and set these modes. The master setup remote is also required for using or configuring other iTV products and accessories.

Commercial Mode: Philips Institutional Televisions are typically configured at the Factory to operate in Commercial mode. When the television is in Commercial mode, access to its operation from its front panel controls or from a guest-mode remote can be limited, depending upon the settings of the Institutional TV features. For examples, the unit's front panel controls can be "locked-out" (rendered inoperable), only certain channels can be selected, and/or the volume can be limited to a given range.

Consumer Mode: When in the Consumer mode, the unit operates as a standard TV, bypassing the Institutional Television feature set, thus allowing normal initial power ON, channel selection, and volume control (as well as a variety of selectable Menu features). When the TV is in Consumer mode, Philips RC-5 system 0 (guest-mode) remotes, such as the RC2524BK and the RL9820BK (optional accessories) can access the Consumer-mode Main Menu, and configure the television to the full extent offered in this mode. Guest-mode 21-button remotes such as the RC2524BK use the Menu button to access the Consumer menu. Guest-mode 20-button remotes such as the RL9820BK, which do not have a Menu button, use the Sleep button to access the Consumer menu. Simultaneously pressing the front panel's Volume - and Volume + buttons also invokes the Consumer menu.

Identifying the Operational Mode: To identify the television's operational mode, a system 7 (commercial setup mode) master setup remote (optional accessory, RG4172BK or RC2573GR) must be used. First, place the setup remote in setup mode. To place the RG4172BK in setup mode, press TV SETUP. **To place the RC2573GR in setup mode, set the switch to the TV SETUP position.** Then press Recall. Television status information similar, but not necessarily identical to the following will appear on-screen.

STATUS ITEM	STATUS DATA	MEANING
SYSTEM STATUS		Information title
MODE	COMMERCIAL / CONSUMER	Operational mode
CHANNEL	CHANNEL, INPUT (CHANNEL, INPUT)	Currently-tuned channel / input
DCM	OFF / ON	Data Communications Module offline / online
CODES	209 222 1 33	Internal data for factory / service use.
SIGNAL	TUNED / NOT TUNED	Valid signal present / absent
OP HRS	0031h	Number of cumulative hours unit has been in operation (hexadecimal).
ERRORS	0 0 0 0 0	Internal data for factory / service use.
VERSION	3.3	Television microprocessor software version.

NOTE: THE ACTUAL STATUS SCREEN WILL VARY DEPENDING UPON THE MODEL AND MANUFACTURE DATE OF THE SPECIFIC PHILIPS INSTITUTIONAL TELEVISION.

Changing Operational Modes: If the Mode Status shows that your television is set to CONSUMER, contact Contract Video Specialists by emailing info@contractvideo.com for directions on how to change the television back to COMMERCIAL.

Accessing The Philips Institutional Television Menu

Regardless of the operational mode in which the Philips Institutional Television has been placed, its control settings and features can be accessed by placing the RG4172BK / RC2573GR setup remote in setup mode and pressing the M (menu) button. If the television is in Commercial Mode, the Institutional features will be accessible. On the following page, a typical late-model menu is shown. The specific items contained in the menus of your Philips Institutional television will vary depending upon the operational mode and the model and manufacture date of the specific Philips Institutional television.

The following table summarizes the Commercial and Consumer menu items available on a typical late-model Philips Institutional television, and is intended merely to be representative of the types of items and features in the two modes. The column labeled *CONSUMER* indicates the Main Menu items that are available when the television is in Consumer mode, and *Menu* or *Sleep* is pressed on a guest-mode remote (or RG4172BK/RC2573GR master setup remote in guest mode). The column labeled *COMMERCIAL* indicates the Setup Menu items available with the RG4172BK / RC2573GR master setup remote whenever the setup remote is in setup mode.

NOTE: The specific items contained in the menus of your Philips Institutional television will vary depending upon the operational mode and the model and manufacture date of the specific Philips Institutional television.

MENU ITEM	SETTINGS / OPTIONS	COMMERCIAL	CONSUMER
(MENU TITLE)	SETUP MENU / MAIN MENU	SETUP MENU	MAIN MENU
LANGUAGE	ENGLISH/ESPAÑOL/FRANCAIS	X	X
CHANNEL INSTALL	>	X	X
CABLE TUNING	ON/OFF	X	X
BRIGHTNESS	--- 31	X	X
COLOR	--- 31	X	X
CONTRAST	--- 31	X	X
SHARPNESS	--- 31	X	X
TINT	--- 0	X	X
NOISE REDUCTION	ON/OFF	X	X
SOUND MODE	MONO / STEREO	X	X
SAP	OFF / NO SAP / ON	X	X
AUDIO OUT	FIXED / VARIABLE	X	X
BALANCE	---- --- 0	X	X
TREBLE	--- 31	X	X
BASS	--- 31	X	X
INCRED STEREO	ON / OFF	X	X
AVL	ON / OFF	X	
VOLUME BAR	ON / OFF	X	
MIN VOLUME		X	
MAX VOLUME	----- 63	X	
SWITCH ON VOLUME	--- 31 / STANDARD	X	
SWITCH ON CHANNEL	Ch. 1-12 5 / FRONT / AUX / S-VIDEO / CVI / STANDARD	X	
POWER ON	STANDARD / FORCED	X	
CHANNEL DISPLAY	NUMBER / LABEL / ALL / NONE	X	
KEYBOARD LOCK	ON / OFF	X	X
ESP	1-99 / OFF	X	X
AUDIO/VIDEO MUTE	OFF / BLACK / BLUE	X	
EXT AUD / VID OUT	ON / OFF	X	
WELCOME MESSAGE	>	X	X
CHANNEL GUIDE	POWER ON/OFF/ON	X	
REMINDER	ON / OFF	X	
3 DIGIT ENTRY	ON / OFF	X	X
A/CH A/V SWITCH	ON / OFF	X	
CC	OFF/CC-1/CC-2/CC ON MUTE	X	
SAVE CC	ON / OFF	X	
V-CHIP MENU ITEM	ON / OFF .	X	X
SAVE V-CHIP	ON / OFF		
V-CHIP SETUP	>	X	
SLEEPTIMER	OFF/15/30/45/S0/90/120/180/240	X	X
SECURITY	STANDARD/HIGH	X	
EXIT	>	X	